



Highlights

- LCD pans side-to-side for closer access; arm also reaches low for people wearing bifocals or using a tablet PC
- Front handle on worksurface, premium casters, and lightweight design enables cart to easily maneuver into tight spaces
- Flexible, open architecture design is ready for the computer equipment of today and tomorrow
- Constant Force patented lift technology provides fluid, one-touch adjustment
- Work sitting or standing with the ergonomic height adjustment range
- Barcode scanner holder provides easy access to hand-held scanner
- Very accessible—facilitates ADA (Americans with Disabilities Act) compliant computing initiatives, such as mobile kiosks
- Save time and money utilizing a network of certified professionals to deploy Neo-Flex carts in your facility with an Ergotron Service Program (not available in all areas)



Ergotron®

Neo-Flex® LCD and Laptop Carts



Affordable, mobile ergonomic computing

Designed for manufacturing floors, clinical documentation, labs, distribution centers, and high activity areas, the light-weight streamlined Neo-Flex LCD Cart transforms any space into a productive sit-stand computing environment. Creating an optimal platform for true point-of-need data input, the Neo-Flex cart helps improve viewing comfort, increase user accuracy and productivity while supporting wireless initiatives in any facility.

The Neo-Flex LCD Cart features Ergotron's Constant Force patented lift technology, 27-inch (68 cm) height range, independent adjustment for LCD Arm, 65° screen tilt and large worksurface. Complete with a flexible open architecture design, this solution supports mobile computing needs today and tomorrow.

The Laptop Cart features Ergotron's Constant Force patented lift technology, 20-inch (51 cm) effortless lift range, and an integrated laptop security system for theft deterrence and stability. Complete with a flexible open architecture design, this secure, low-cost solution supports mobile computing needs today and tomorrow.



- ① Integrated security system for 13–17" laptops, allows cooling airflow, works with port-replicators, avoids use of adhesive and Velcro, uses unique security fastener and driver
- ② Worksurface: 16.5" W x 20.5" D (42 x 52 cm)
- ③ Power brick mounts under worksurface in cable storage area
- ④ Durable, easy-to-clean exterior composed of aluminum, high-grade plastic and zinc-plated/powder coated painted steel
- ⑤ Includes power strip and cable wrap mounting bracket
- ⑥ Cables along main column are secured with "zip-ties" at provided attachment points
- ⑦ Wheel-to-wheel base: 17.5" x 22.8" (44 x 58,2 cm)
Patented Constant Force (CF) lift-and-pivot motion technology

- ① LCD pans side-to-side for closer access; arm also reaches low for people wearing bifocals or using a tablet PC
- ② Conveniently attaches VESA-compliant (75 x 75 or 100 x 100 mm) thin client CPU to the underside of the worksurface
- ③ Work sitting or standing with the ergonomic 27-inch (68 cm) height adjustment range
- ④ Flexible, open architecture design is ready for the computer equipment of today and tomorrow
- ⑤ Safe and neat routing of cables through the expansive cable management storage area
Constant Force patented lift technology provides fluid, one-touch adjustment
Light weight, actual cart weighs under 38 lbs (17 kg)



NF Cart Laptop Vertical Kit
97-546



- ④ Suggested accessories:
NF Cart Handle and Basket Kit 97-545 (grey)
Universal CPU Holder 80-105-064 (dark grey)
NF Cart Wire Basket Kit 97-544

Product Name	Neo-Flex Laptop Cart	Neo-Flex LCD Cart
Part Number	24-205-214 (two-toned grey)	24-206-214 (two-toned grey)
Product Includes	Integrated worksurface/keyboard tray with left/right mouse tray, scanner holder bracket, mouse holder, cable storage area, bracket for power strip, four dual casters (two locking), laptop security system	LCD arm, integrated worksurface/keyboard tray with left/right mouse tray, scanner holder bracket, mouse holder, cable storage area, bracket for power strip, four dual casters (two locking), quick-release VESA-CPU mount
Shipping Dimensions	21.75" x 15" x 45.25" (552 x 380 x 1150 mm)	21.75" x 15" x 45.25" (552 x 380 x 1150 mm)
Weight	Shipping weight 52 lbs (23,6 kg); actual weight 34 lbs (18 kg)	Shipping weight 56 lbs (25,4 kg); actual weight 38 lbs (17 kg)
Warranty	3 years	3 years
Weight Capacity	Laptops up to 8 pounds (3,6 kg)	Monitors up to 12 pounds (5,5 kg)
Compatible Display(s)	Almost any notebook computer, with or without docking station	Accommodates most VESA compatible monitors, up to 12 pounds

© 2010 Ergotron, Inc. rev. 10/14/2010 e-05-073-EA Content is subject to change without notification

Americas Sales and Corporate Headquarters
St. Paul, MN USA
(800) 888-8458
+1-651-681-7600
www.ergotron.com
sales@ergotron.com

EMEA Sales
Amersfoort, The Netherlands
+31 33 45 45 600
www.ergotron.com
info.eu@ergotron.com

APAC Sales
Tokyo, Japan
www.ergotron.com
apaccustomerservice@ergotron.com

Worldwide OEM Sales
www.ergotron.com
info.oem@ergotron.com

