

ergotron®

moving you forward

YES24 Charging Cart for Mini-laptops

- Charge, store and transport up to 24 devices
- Perfect for Chromebooks™, Netbooks, Surface Pro and MacBook Air® devices up to 14"
- Adjust the interior to fit your devices: raise and lower the Lift-N-Set Shelves and remove/adjust the Pop-N-Go Bay Dividers to create the right bay size
- Compact design maneuvers easily through crowded hallways and into tight spaces
- Devices stay secure with keyed locks on each door, complete with brackets for your own padlock and a two-point locking system
- Easy to steer with 4" dual-wheel rubber casters and a wide ergonomic handle



ERGOTRON SAYS "YES!" TO ALL YOUR DEVICES

Charge and store any mix of up to 24 Chromebooks, Netbooks and Tablets. Do more than just charge your classroom devices. Help batteries last longer and charge faster with the Zip40 Charging or Zip40 Charging and Management Carts. Now designed with a sturdier handle, removable door and dual-wheel locking casters, this charging cart lets you zip through crowded classrooms. And with adjustable dividers, you have the flexibility to fit up to 40 tablets and Chromebooks or 30 full-size laptops. It ships fully assembled to give you more time to focus on what matters most—your students. Learn more.



YES24 Charging Cart for Mini-laptops



EACH LIFT-N-SET SHELF CAN BE REPOSITIONED TO CREATE LARGER OR SMALLER VERTICAL SPACES TO FIT YOUR DEVICES



POP-N-GO BAY DIVIDERS ARE MADE OF TOUGH ABS POLYMER AND CAN BE MOVED TO CREATE THE PERFECT BAY WIDTH FOR YOUR DEVICES



MIX AND MATCH DEVICES—THE INTERIOR IS YOURS TO CONFIGURE



QUICKLY SEE THE STATUS OF THE CART WITH A LIGHTED ON/OFF SWITCH



THE CABLE CHANNELS ON TOP OF EACH BAY DIVIDER ARE EASY TO REACH, EASY TO SEE AND EASY TO WIRE



DOORS, SIDE PANELS AND INTERIOR PANELS ARE VENTILATED SO THAT DEVICES STAY COOL



INTEGRATED KEYED LOCKS HAVE BRACKETS FOR YOUR OWN PADLOCK



DEVICES ARE SECURE WITH A 2-POINT LOCKING SYSTEM ON EACH DOOR



THE COMFORT EDGE TOP SURFACE HAS A LIP TO PREVENT ITEMS FROM ROLLING OFF



4" LOCKING RUBBER CASTERS ROLL EASILY OVER UNEVEN SURFACES

Part # (color)	US/CA/MX YES24GMPW4 (white/grey)
Compatible Devices	Fits all shapes and sizes of screens up to 13"—and some up to 14"—with and without cases (Verify device dimensions for compatibility)
Screen Size	≤ 13.3" See website for details
AC Charge	Outlet strips include plenty of space to fit oversized wall plug or brick-style AC adapters; use adapters that come with devices
Auxiliary Outlets	3 external receptacles
Number of Devices	Up to 24 with 1.45" wide (3,6 cm) slots
Slot Size	Ships configured for 24 units with 1.45" (3,56 cm) wide bays. Simple shelf adjustment lets you position shelves at any height in 2/3" (1,7 cm) increments and store your devices in landscape or portrait orientation, depending on size and the position of the power inlet and on/off button
Certifications	UL 60950 and CAN/CSA C22 2 No. 60950
Security	2-point locking steel doors with key lock; brackets included for your own padlock
Power System	120Vac, 60Hz, 12Amps See website for details
Weight Capacity	≤ 5 lbs (≤ 2.3 kg) See website for details
Product Dimensions	27.75" x 24.25" x 42" (70 x 62 x 107 cm)
Product Weight	143 lbs (65 kg)
Shipping Dimensions	27.6" x 31.5" x 48.8" (70 x 80 x 124 cm)
Shipping Weight	190 lbs (86 kg)
Warranty	Lifetime for mechanical components; three (3) years for electrical system; one (1) year for cables

Download additional resources at ergotron.com.

For more information:

NORTH AMERICA: 800.888.8458 / +1.651.681.7600 / sales@ergotron.com

EMEA: +31.33.45.45.600 / info.eu@ergotron.com

APAC: apaccustomerservice@ergotron.com

OEM: info@oem.ergotron.com

© Ergotron, Inc. 08.08.2019

Literature made in the U.S.A.

Content subject to change.

Ergotron devices are not intended to cure, treat, mitigate or prevent any disease.

Patent information available at www.ergotron.com/patents.

