# ergotron® moving you forward

## Tablet Management — for iPad®

- Design accommodates iPad Pro, iPad Air 2, iPad (4th and 5th generation) and iPad mini devices
- Multiple capacity options to sync, charge, transport and secure up to 32 tablets
- Full 2.4A charging power for Apple devices
- Lightning<sup>™</sup> cables installed
- Charge all tablets simultaneously with one power cord to the wall socket
- Switch from charge to sync mode by connecting a Macintosh computer or PC.
   Charging status is visible using the Individual Status Indicator (ISI) LED feature
- Desktop units are available and can be secured to a worksurface
- Up to 47% smaller and lighter (unloaded) than competitive product



SYNC AND CHARGE. LIGHTWEIGHT, COMPACT, EASY TO MANEUVER, SECURE AND COST-EFFECTIVE DESIGN.

#### Pre-installed Lightning cables

Sync, charge, secure and manage up to 32 devices. Fully assembled with Lightning cables installed, this cart is ready to roll right out of the box. This compact cart accommodates iPad Pro, iPad Air, iPad (4th and 5th generation) and iPad mini devices.

Durable steel doors with robust three-point lock and key assembly provide strong theft deterrence.

Full 2.4A charging capability Charges iPad Air in approximately 4 hours — 33% faster than 2.1A solutions

### Tablet Management — for iPad®

#### Ready to Roll

 Fully assembled with Lightning cables installed, this cart is ready to roll right out of the box. Just plug in your iPad devices to get started. Sync, charge, transport and secure up to 16, 32 or 48 tablets

#### Top-Rated Sync & Charge

- Improved charging system provides a full 2.4A charging current per device — charging an iPad Air in less than 4 hours
- Built-in syncing capability; simultaneously sync up to 32 devices by connecting your laptop via the cart USB port
- · Made for iPad certified
- Compatible with iPad Pro, iPad Air, iPad (4th and 5th generation) and iPad mini devices. Lightning cables come pre-installed so the cart is ready to charge immediately
- · Accommodates most iPad cases
- LED Individual Status Indicators (ISI) monitor charging progress of each tablet

#### Super Compact Design

 Carts feature a small footprint making them easy to maneuver through tight aisles and easy to store

- Up to 47% smaller, 47% lighter (unloaded ) than competitive product *Solid. Durable Construction*
- Steel tube and aluminium extrusion framework; steel access doors
- Durable, easy-to-clean exterior composed of high-grade fire-retardant ABS
- Clean, neat cable management within dedicated drawer located within each module. Secure drawer is separate from iPad compartment, limiting unauthorized access to cables

#### Safe & Secure

- Tested and certified to UL 60950-1 and UL 1678 standards, FCC requirements and all applicable country-specific regulations
- Durable steel doors with three-point lock assembly provide strong theft deterrence; optional security bracket kit provides ability to secure entire cart to floor or wall
- Fan and ventilation system maintains safe operating temperatures
- Ergotron not only uses UL-certified components, but goes a step further to have UL certify the entire system to guarantee safe use within the classroom, healthcare, or enterprise setting. Tested and certified to UL 60950-1 and UL 1667 standards, FCC requirements, and all applicable country-specific regulations



Security Bracket Accessory Kit 97-735

#### Tablet Management Cart 32 2.4 with ISI

Part # (black) Lightning Cables Sync	DM32-1004-2 EU  Installed  Yes, USB or wireless
	mounts.
Svnc	Voc LISP or wireless
-,	res, OSB of Wileless
Charge	2.4A via USB
Compatible Devices	iPad Pro (9.7-inch), iPad Air 2, iPad Air, iPad (4th and 5th generation), iPad mini 4, iPad mini 3, iPad mini 2, iPad mini (Most cases fit)
# of Devices	32
UL Certification	Yes
Slot Size	7.9"H x 11.3"W x 0.85"D (20 x 28,8 x 2,2 cm) (Tablet, power cord, and any cover or case must fit within these dimensions)
Product Dimension	23"W x 18.4"D x 39.3"H (58,4 x 46,7 x 100 cm)
Unloaded Product Weight	100 lbs (45,4 kg)
Warranty	5 year warranty; 1 year warranty on all non-power supply electronic systems; 2 year warranty on all power modules

<sup>&</sup>quot;Made for iPad" means that an electronic accessory has been designed to connect specifically to iPad devices and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Please note that the use of this accessory with iPad devices may affect wireless performance.



Download additional resources at ergotron.com. For more information:

USA & Canada: 800.888.8458 / +1.651.681.7600 / insidesales@ergotron.com EMEA: +31.33.45.45.600 / info.eu@ergotron.com

APAC: apaccustomerservice@ergotron.com LATAM: +1.800.681.1820 / info.latam@ergotron.com

Custom: custom@ergotron.com

© Ergotron, Inc. 11.01.2021
Literature made in the U.S.A. Content subject to change.
Ergotron devices are not intended to cure, treat, mitigate or prevent any disease.
Patent information available at www.ergotron.com/patents.
WorkFit, StyleView, LearnFit, Neo-Flex, PowerShuttle, LiFeKinnex, CareFit and eKinnex are trademarks of Ergotron.

