

# ergotron®

*moving you forward*

## **Zip12 Charging Wall Cabinet**

- Open architecture design works with most tablets (including Android, Windows and iPad) and Chromebooks with up to 11.6" displays
- Designed to be compatible with a wide variety of manufacturers such as Microsoft, Samsung, Apple, Lenovo, HP, Dell, Amazon, Asus, Acer and many others
- Smooth sliding door provides easy access to devices and stays within the sleek profile
- Show & Stow™ technology tilting tablet trays make loading and unloading devices simple. Pull trays out to load or unload and they will automatically retract
- Low-profile design protrudes less than 6" (15,2 cm) from the wall saving space
- Quick, simple installation includes mounting template, mounting bracket and hardware. Mount the bracket on the wall, hang the cabinet and secure with two heavy-duty screws
- Six-point locking bracket keeps devices safe and secure



## POWER UP!

This slim storage cabinet is perfect for charging and securing up to 12 tablets and Chromebooks. It's designed to be compatible with a wide variety of manufacturers like Microsoft, Samsung, Apple, Lenovo, HP, Dell, Amazon, Asus, Acer and many others.

Features include a space-saving cabinet profile and easy device access with Show & Stow technology.

# Zip12 Charging Wall Cabinet

- Snap-in tablet tray cable clips make setup simple and keep the device cables perfectly positioned for easy insertion
- Separate AC adapter storage area for easy one-time setup and clean cable storage. Custom country-specific outlet strip includes plenty of space to work with oversized wall adapters and mini-bricks
- For user and equipment safety, the entire cabinet is tested and certified to UL 60950
- Includes charging and storage cabinet, wall-mounting bracket, mounting hardware for wood stud, concrete and hollow-wall installation, installation template, 6' (1,8 m) power cord, key
- Individual device maximum dimensions 11.4"W x 8.9"H x 1.0"D (29 x 23 x 2,5 cm) including case and cord
- Individual device maximum weight 3 lbs (1,4 kg). Total rated weight capacity 44.4 lbs (20,1 kg)
- Uses the AC adapters that come with each device. AC adapters are not included
- Environmentally clean: RoHS, REACH, WEEE and EU (94/620EC) packaging compliant
- Temperature range: Operating 0° to 30°C (32° to 86°F) Storage -40°C to -60°C (-40° to 140°F)
- Relative humidity (maximum): Operating 10% to 90% (non-condensing) Storage 5% to 95% (non-condensing)
- Cooling/ventilation: One 12V DC continuous operation fan

Easy-to-turn wing knob lock engages 6-point locking bracket to ensure secure tablet storage



Country-specific 12-receptacle outlet strip is designed to work with oversized wall adapters and mini-sized bricks. AC adapter maximum dimensions 4.1"H x 2"W x 4"D (10,4 x 5,0 x 10,1 cm)



Ergotron not only uses UL-certified components, but goes a step further to have UL certify the entire system to guarantee safe use within the classroom, media center and around the campus. Ergotron products are tested and certified to UL 60950-1 standards, FCC requirements and all applicable country-specific regulations.

Make sure to require this of your device charging solutions. Safe for your devices, your building and your staff.

Part #	US/CA/MX: DM12-1006-1 EU: DM12-1006-2 UK: DM12-1006-3 HK/MY/SG: DM12-1006-3 AU/NZ: DM12-1006-4 CN: DM12-1006-5
Charge Method	AC
Screen Size	≤ 12" See website for details
# of Devices	12
Slot Size	11.4" x 8.9" x 1.0" (29 x 23 x 2,5 cm)
UL Certification	Full UL 60950 certification
Secure	Locking steel doors
Weight Capacity	≤ 3 lbs (≤ 1,4 kg) See website for details
Product Dimensions	26.4"W x 35.6"H x 5.9"D (66,9 x 90,5 x 15 cm)
Product Weight	64.5 lb (29,3 kg)
Shipping Dimensions	40.9"W x 28.9"D x 8.4"H (104 x 73,5 x 21,4 cm)
Shipping Weight	77 lb (34,9 kg)
Warranty	Limited lifetime for the frame; 5 years for other mechanical components; 3 years for electrical components; 1 year for cables

Download additional resources at [ergotron.com](http://ergotron.com).

For more information:

USA & Canada: 800.888.8458 / +1.651.681.7600 / [insidesales@ergotron.com](mailto:insidesales@ergotron.com)

EMEA: +31.33.45.45.600 / [info.eu@ergotron.com](mailto:info.eu@ergotron.com)

APAC: [apaccustomerservice@ergotron.com](mailto:apaccustomerservice@ergotron.com)

LATAM: +1.800.681.1820 / [info.latam@ergotron.com](mailto:info.latam@ergotron.com)

Custom: [custom@ergotron.com](mailto:custom@ergotron.com)

© Ergotron, Inc. 10.05.2020

Literature made in the U.S.A. Content subject to change.

Ergotron devices are not intended to cure, treat, mitigate or prevent any disease.

Patent information available at [www.ergotron.com/patents](http://www.ergotron.com/patents).

WorkFit, StyleView, LearnFit, Neo-Flex, PowerShuttle, LiFeKinex, CareFit

and eKinex are trademarks of Ergotron.

